



Supply Tube

Disconnect the supply tube on your toilet.

Written By: Ron Davis



INTRODUCTION

Prereq-only guide for disconnecting the supply tube from a gravity flush toilet.

Step 1 — Shutting off the Water Supply to a Toilet



- Shut off the stop valve underneath the toilet by turning it clockwise until it becomes tight.

i The appearance of this valve may differ from toilet to toilet, but most operate the same.

Step 2 — Supply Tube



- Place a bucket under the supply tube to catch any dripping water.
- Turn the coupling nut on the supply tube clockwise until it releases from the threaded shank on the bottom of the tank.

To reassemble your device, follow these instructions in reverse order.

